

#### STEP 4 - JAMB AND HEAD FLASHING



- 1 Install self-adhesive jamb flashing extending 4" above the top of the head flange and even with the bottom of the sill flashing.
- 2 Install self-adhesive head flashing extending 1" beyond the jamb flashing.
- 3 If housewrap has been installed, be sure that the head flap, when it is folded down, will cover the top of the flashing.

#### STEP 6 - IF APRON WAS INSTALLED



- 1 If an apron was installed under the window, slip the housewrap or building paper under the apron.
- 2 Tape the edges where the housewrap meets the window flange if housewrap is installed after flashing.
- 3 If building paper is used, embed the edges in a bead of sealant where the paper meets the window flange.

#### STEP 5 - SEAL ROUGH OPENING GAP



- 1 On the interior side of the window, seal gap between the window and the rough opening with appropriate sealant.

#### STEP 6 - IF HEAD FLAP WAS CREATED



- 1 If headflap was created, fold it over the head flashing and tape across the top window flange and the 45° angle seams.